


RAAC

MEASUREMENTS INSTRUCTIONS - FOR USING A PC


Download and install Audacity (<https://www.audacityteam.org/>) - a free, open source, easy-to-use, multi-track audio editor and recorder for Windows, macOS, GNU/Linux and other operating systems.

For software and hardware settings please follow the instructions available in the Audacity manual and many examples available on online.


1) Start Audacity and change the export audio settings (Edit --> Preferences) to »Use Advanced Mixing Options«. Press "OK."




3) Import the downloaded audio sample file (File --> Import audio)



3) Start recording (Shift + R) and a new track will be automatically created



4) Export the recording to a wave file (File → Export → Export as wave) and confirm the Advanced Mixing Options



5) Upload the exported wave file to the RAAC service at www.soundprof.com

If the measurement is repeated in several microphone positions, just perform step 3) multiple times. Keep in mind that the already recorded tracks have to be muted (not played back during the measurement).

It is possible also to use multiple microphones for recording – please refer to the manual.